HeatWork®

Tecnical Support Phone : +47 488 93 271
Heatwork Office Phone : +47 769 65 890

DRAWING REV

HW-1800/3600 AUTOSTART SYSTEM



HeatWork®

Tecnical Support Phone : +47 488 93 271
Heatwork Office Phone : +47 769 65 890

DRAWING REV

HW-1800/3600 FLUID SYSTEM

FRE

L1 L2 PE

24V +
Li2
Li1
COM -

R1c
R1b
R1a
R1b
R1a
R1c

T1 T2 T3 PE PE

Burner Switch

KBR/4

MA1 2 1
MA2 2 1

Valve Boiler

Valve Hose Reel

EMERGENCY STOP
11 X1 22
12 X2 23

REK 2

XM1
16 16
7 7
8 8
15 15

PUMP VTV
M
3~

XM2
3 3
1 1
9 9
11 11
32

LEVEL VTV
2
1

XNV
2 2
1 1

XM2
2 2
10 10

XM2
22 22
21 GPS HOUR PUMP

XM2
17 17
25 25
PE PE

KMA
3 1 9 7 A1
2 8 A2

PUMP SWITCH
1 0 2 3 1 5 7
4 2 6 8

BA
1 2

6A
3 KNE / KAG
1 KNE / KAG

PQ
1 KNE / KAG
3 KNE / KAG

+ − Battery

HeatWork®

Tecnical Support Phone : +47 488 93 271
Heatwork Office Phone : +47 769 65 890

DRAWING REV

HW-1800/3600 BOILER SYSTEM

